

TECHNICAL DATA SHEET

OVERLAP AND REPAIR ADHESIVE

Description:

Border, Overlap and Repair Adhesive is a ready mixed adhesive specially formulated for adhering overlaps and seams and for applying borders. Ideal for repairs to damaged or torn wallpapers. Suitable for most wallcovering types, including paper backed vinyl to existing vinyl wallcovering. It contains efficient fungicides to protect against mould growth.

Surface Preparation:

Surfaces should be sound, dry, clean and free from damp, dust and grease.

Adhesive Application:

Overlapping Seams:

Spread the adhesive evenly on the surface of the bottom piece of wallcovering, and then press overlap down firmly.

Wallpaper Repairs:

Moisten the back of the wallcovering first. Spread adhesive on to the exposed wall substrate and press the wallcovering firmly into place.

Applying Borders:

Using a brush or spatula evenly spread the adhesive to the reverse side of the border. Allow to soak (follow border manufacturers guidelines). Apply the Border to the wall substrate and press firmly into place. Remove any excess adhesive immediately with a damp sponge.

Hanging Instructions:

It is important that the Wallcovering manufacturer's hanging instructions are followed at all times. If in doubt, seek advice.

Coverage:

1 kg is sufficient to apply 50 metres of 10cm border.

HEALTH AND SAFETY - Refer to separate sheet

This information supplied is, to the best of knowledge, true and accurate, but any recommendations or suggestions made are without guarantee since the conditions of use are beyond our control.

Other Information:

Revision date: July 2018